



BLUESOUND®

BP100 | BATTERY PACK FOR PULSE FLEX



Add the BP100 Battery Pack to the PULSE FLEX speaker and listen to music virtually wherever and whenever. Play music in the park with your smartphone, tablet or any Bluetooth-enabled device, or connect the battery-powered PULSE FLEX to your home network and listen wire-free anywhere in or outside the home.

Rechargeable with the current battery life displayed in the Player Drawer of the app, the BP100 attaches to the back of the PULSE FLEX and offers up to six hours of listening on a single charge. For charging, simply plug the PULSE FLEX into a power source or an outlet via the AC power cord with the battery pack attached, and you're ready to go again.

STREAM YOUR MUSIC VIA aptX® BLUETOOTH, WIFI, OR CONNECT OTHER DEVICES USING HOTSPOT MODE

RECHARGEABLE BATTERY PACK WITH EIGHT RECHARGEABLE AA NiMH BATTERIES INCLUDED

SIX HOURS* OF LONG-LASTING LISTENING ON A SINGLE CHARGE WITH aptX® BLUETOOTH, WIFI OR A CONNECTED DEVICE

**BATTERY LIFE VARIES DEPENDING ON VOLUME LEVELS*

AVAILABLE IN MATTE BLACK AND WHITE FINISHES TO MATCH THE PULSE FLEX

DIMENSIONS:
82 x 27.5 x 113 mm/3.2 x 1.1 x 4.4 in (W x H x D)

WEIGHT: 0.32 kg/0.7 lb

BLUESOUND®

© Bluesound International. Bluesound, the stylized wordmark and "B" logotype, the phrase "HiFi for a wireless generation", PULSE FLEX and all other Bluesound product names and taglines are trademarks or registered trademarks of Bluesound International, a division of Lenbrook Industries Limited. All other logos and services are trademarks or service marks of their respective owners. 16-051 © 05/16 Bluesound.